

Kallise Tables | Disassembly & Recycling Instructions

Recommended tools:

- Safety glasses
- Work gloves
- Hammer
- Chisel
- Pipe wrench
- Large locking pliers
- Pry bar
- Phillips screw driver

Recyclable materials:

A – Glides = HDPE Plastic

B – Legs = Steel, or Wood*

C – Cam & Pin Assembly = Steel

*may be recyclable, refer to your local municipality.

Steps to disassemble:

1. Remove glides from the legs.
2. Remove the legs from cam & pin assemblies. Heating can assist in loosening the epoxy that keeps them in place.
3. Remove the cam & pin assemblies from the table top. Heating can assist in loosening the epoxy that keeps them in place.

These instructions are applicable to the following products:

- Kallise Table
- Alpine Table
- Pax Table

